



Revised September 2008

PRODUCT BULLETIN

PA-400 Series Ancillary Products for Photosensitive Polyimides

HD Microsystems produces a range of solvent based ancillary products for its line of negative tone photosensitive polyimides. The HD-4100 Series are the premier photosensitive polyimides especially developed for high-performance applications in wafer fab and packaging. These products are engineered to be readily compatible with various thin film metalization schemes, high lead or non-lead solders, various plating solutions and underfill materials. HD-4100 Series polyimides have a high Tg and high elongation. Like most polyimides, HD-4100 Series products are not prone to oxidation and are resistant to most wet and dry chemical processes practiced in wafer fabrication.

Product Codes

A variety of different product codes comprise the HD-4100 series product line. These products all share the same polyimide platform and resolution capability. Please consult the *HD-4100 Series Product Bulletin* or the *HD Microsystems Production Selector Guide* for the best product code for your application.

Developer

The standard developer for HD-4100 series products is **PA-401D**, which is based on cyclopentanone [CPO]. PA-401D offers good solubility and an evenly controlled develop rate. It is also the recommended edge bead remover for all HD-4100 series products.

Faster developing can be achieved with **PA-400D**. The major solvent component for PA-400D is gamma

butyrolactone [GBL]. The process window for this developer is not as wide PA-401D for some applications. These products should be considered if faster throughput is desired or if an HD-4000 polyimide product is being processed on a coater track already plumbed with one of these developer types. The develop rate of PA-400D is 1.25X compared with PA-401D.

Rinse

The preferred rinse for HD-4000 series products is **PA-400R** and based on PGMEA.

Edge Bead Remover & Backside Rinse

PA-401D is the recommended edge bead remover [EBR] and backside rinse all for HD-4100 products. In addition, NMP or GBL based solvents such as PA-400D can also be used. However both these solvents have a high boiling point and do not readily spin-dry on standard wafer coater tracks. This often results in a residue on the backside of coated wafers and/or slight crazing of the uncured polyimide layer at wafer edge.

Availability

HD Microsystems produces all the ancillaries referenced in this bulletin in a variety of lot sizes and in 4 liter, 20 liter and 200 liter container sizes. For further information, please contact your area HD Microsystems Technical Representative or distributor.

United States

HD MicroSystems
 250 Cheesequake Road
 Parlin, NJ 08859-1241
 800-346-5656 ext. 13, 14 (Phone)
 732-613-2502 (Fax)

10080 North Wolfe Road, SW3-200
 Cupertino, CA 95014
 800-346-5656 ext. 11 (Phone)
 408-996-0508 (Fax)

Japan

HD MicroSystems, Ltd.
 Nikkyohan Building 3F
 4-25 Koraku 1-Chome, Bunkyo-ku
 Tokyo 112-0004, Japan
 81-3-3868-8124 (Phone)
 81-3-3868-8126 (Fax)

Internet

www.hdmicrosystems.com

Europe

HD MicroSystems GmbH
 Hugentottenallee 173-175
 63263 Neu-Isenburg
 Germany
 49-6102-18-1823 (Phone)
 49-6102-18-1824 (Fax)

HD MicroSystems liability is expressly limited by HD MicroSystems' Conditions of Sale shown on Seller's price list or Buyer's copy of Seller's order acknowledgement form (if used) and Seller's invoice. All technical advice, recommendations and services are rendered by the Seller free of charge. While based on data believed to be reliable, they are intended for use by skilled persons at their own risk. Seller assumes no responsibility to Buyer for events resulting or damages incurred from their use. They are not to be taken as a license to operate under or intended to suggest infringement of any existing patent.

Caution: Do not use in medical applications involving permanent implantation in the human body.